



$$z = \frac{Y^2}{R \left(1 + \sqrt{1 - (1+k) \frac{Y^2}{R^2}} \right)} + A_4 Y^4 + A_6 Y^6 + \dots + A_n Y^n$$

	SURFACE 1	SURFACE 2
SURFACE TYPE	ASPHERIC	PLANO
CLEAR APERTURE (CA)	ø3.00mm	ø2.44mm MIN.
RADIUS OF CURVATURE	2.16497	INF.
k	-1.12249	0
A_4	7.50357E-003	0
A_6	1.19911E-004	0
A_8	-9.99584E-006	0
A_{10}	-2.53542E-006	0
A_{12}	-1.25139E-007	0
A_{14}	0	0

VARIABLES	
z	SURFACE PROFILE
Y	DISTANCE FROM OPTICAL AXIS
R	RADIUS OF CURVATURE
k	CONIC CONSTANT
A_4	4th ORDER ASPHERIC COEFFICIENT
A_6	6th ORDER ASPHERIC COEFFICIENT
A_n	nth ORDER ASPHERIC COEFFICIENT



NUMERICAL APERTURE	0.55
EFFECTIVE FOCAL LENGTH	2.73mm

NOTES :

- MATERIAL: D-ZLAF52LA
- WAVEFRONT ABERRATION (RMS): <0.05λ @ 632.8nm
- AR COATING: 375-650 nm
REFLECTIVITY R<1.00%

ALL DIMENSIONS ARE IN MILLIMETERS		A	N/A	ORIGINAL ISSUE	C.M.	16-SEP-2019	
DRAWN BY: P. SUMMERS	DATE: 9/16/2019	REV.	ECR REF#	DESCRIPTION	ENG. BY	DATE	
CHECKED BY:	DATE:	UNLESS NOTED OTHERWISE, DIMENSIONS ARE IN MILLIMETERS. INCHES ARE IN SQUARE BRACKETS AND TOLERANCES APPLY AS SHOWN BELOW.				PART BARCODE #: 506	
M/S CHECKED BY:	DATE:	INCHES				219 WESTBROOK ROAD OTTAWA, ONTARIO CANADA K0A 1L0	
AP/VD BY:	DATE:	MILLIMETERS				www.ozoptics.com	
PROJECTION:		DESC: ASPHERIC LENS f=2.7mm, OD=4mm. AR COATED FOR 375-650nm				AS-F2.7-D4-375/650	
CONFIDENTIAL THIS PRINT IS THE EXCLUSIVE PROPERTY OF OZ OPTICS AND MUST BE RETURNED UPON REQUEST. UNAUTHORIZED USE, MANUFACTURE OR REPRODUCTION IN WHOLE OR IN PART IS PROHIBITED.		PART NO.:				REV A	
SURFACE FINISH		MILLED	PROFLED:	SIZE: B	DWG.#	SCALE: 24:1	
		125μ	63μ		4000-0210	SHEET 1 OF 1	

A
4000-0210